

Installation instruction

PrimaCover Carpetsaver

Article no.:

900013, 900014

Non-woven covering with integrated vapour barrier, underside of self-adhesive foil, upper side of absorbent fleece; diffusion closed

- ◆ Easy to install and remove
- ◆ Robust and tear resistant
- ◆ Anti-slip

**Application range**

- ◆ For carpet only.
- ◆ For covering flat carpet floors when working indoors, protects the substrate from mechanical damage and moisture.
- ◆ Chemical evaporation must be completely stopped.
- ◆ Also suitable for stairs with carpeted floor coverings.
- ◆ Not suitable for wet or freshly laid floors. Risk of waterlogging and associated negative changes to the floor.

Installation instruction

- ◆ The substrate must be clean, dry, pressure-resistant, dust- and grease free.
- ◆ Existing floor heating must be switched off.
firmly.
- ◆ Cut the non-woven at edges and corners with a safety knife.
- ◆ Don not lay over cables, protruding objects or other elevations, trip hazard!
- ◆ When laying several sheets next to each other, allow them to overlap by 10cm, press firmly and, if necessary, fix with a suitable tape.

Special feature installation on stairs

- ◆ Lay out the non-woven at the top step far enough (approx. 50cm) and fix the beginning with adhesive tape to the substrate.
- ◆ Lay out the non-woven covering step by step in one go from top to bottom along the shape of the stairs, pressing the fleece on each step (tread and riser) without wrinkles.
- ◆ No moving pieces on the stairs, with exception of the spiral staircase.
- ◆ Lay the fleece on the lowest step far enough into the room and fix it.
- ◆ Regularly check the adhesion of the non-woven to the substrate.
- ◆ Check the surface of the fleece regularly and clean if necessary.
- ◆ If the non-woven is damaged, remove it and lay out new fleece, this is the only way to ensure reliable protection of the substrate.

Note

- ◆ Test the suitability of the product in advance in an inconspicuous place.
- ◆ No acceptance of liability for incorrect usage.
- ◆ It is absolutely necessary to pay attention to the installation instructions and application range!
- ◆ Always store in a dry place!
- ◆ 3 Months after installation, the non-woven should be removed from the surface. It is recommended to protect the non-woven from high temperatures and strong direct sunlight, as this could affect its technical characteristics.

Disposal

The non-woven can be disposed of in landfills after use, with dried paint or plaster residues, in compliance with official regulations.